

USER'S MANUAL BRRC34

RECOIL SERIES

34" AMPLIFIED SOUNDBAR SOUND SYSTEM WITH BLUETOOTH REMOTE CONTROLLER



BOSS Audio Systems 3451 Lunar Court • Oxnard, CA 93030



317 VER:1.1 EN

All rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, incluo photocopying, recording, or other electronic or mechanical methods, without the prior written permission of BOSS AUDIO Inc.



Thank you for purchasing this

3072 **BRRC34 Soundbar Sound System** Please read through these instructions carefully so you will know how to operate your model properly.

After you have finished reading the instructions, keep this document in a safe place for future reference.

THIS PACKAGE CONTAINS

- BRRC34 Soundbar Speaker System

- Bluetooth Multi-Function Controller Kit



- 1.50" Rollbar Mounting Kit

- Quick Connect Power Cable

- 1.75" / 2.00" Rollbar Mounting Kit


- Warranty Card / Facebook Card

User Manual Quick Start Guide / Poster

INFORMATION TO THE USER

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are those of their respective owners.



PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION 1) Power on the *MFC* by long-pressing the **3** Power button for 3 seconds, long-press the

Bluetooth button for 3 seconds, the BLUE LED will start to rapidly flash, signalling that the **MFC** is now ready for **Bluetooth** pairing

NOTE: You have 2 minutes before you must restart this procedure over again.

2) The **MFC** is now in pairing mode:

ANDROID users:

- a. Go into the **Settings Menu** of your device b. Enter the Bluetooth Menu
- c. TURN ON Bluetooth and press SCAN d. "BOSS REBEL UTV" will now be displayed under AVAILABLE DEVICES
- e. If prompted, enter passcode: "0000"

iOS users:


- a. Go into the **Settings Menu** of your **iOS** device
- b. Enter the *Bluetooth Menu* c. TURN ON Bluetooth
- d. "BOSS REBEL UTV" will now be displayed

e. If prompted, enter passcode: "0000"

3) If BOSS REBEL UTV is not seen, repeat the above steps to refresh the "Device List"

4) When the connection is successful a tone will be heard, and the **Bluetooth** LED indicator will light solid, you are now ready to stream music from your favorite media player to the **MFC**

BEFORE YOU START INSTALLATION



To avoid potential shorts in the electrical system, be sure to disconnect the (–) battery cable before installation. Use this unit with a 12-Volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.



When replacing the fuse, be sure to only use a fuse of the rating specified on this product. To avoid short-circuiting, cover any disconnected leads with insulating tape. It is especially important to insulate any unused wires, which if left uncovered may cause a short circuit. When connecting other devices to this product, refer to the manual for the product to be connected. The black cable is ground, make sure to connect the ground wire first. Ensure that the ground wire is properly connected to metal parts of the vehicles body frame or direct to the battery if your vehicle does not have a grounded chassis frame The ground wire of this units power amp and a second powered system must be connected to the frame separately with different screws. If the screw for the ground wire loosens or falls out, it could result in fire or malfunction.

ONBOARD CONTROL PANEL DOME **MUTE - ON/OFF** STATUS INDICATOR LED DOME - ON/OFF WHITE = ON RED = STANDBY

To conserve battery life, the LED Dome light will automatically turn off after 10 minutes when MFC ACC is turned OFF

INFORMATION TO THE USER

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of this device.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. The Bluetooth antenna cannot be removed (or replaced) by user. This equipment complies with FCC/ IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated keeping the radiator at least 20 cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles). Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

□ Relocate or reorient the receiving antenna


□ Increase the separation between the equipment and receiver. □ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

□ Consult the dealer or an experienced radio/TV technician for help.

ADJUSTMENT OR ALTERATIONS OF THIS DEVICE MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

CAUTION!!

BLUETOOTH OPERATION



RECONNECTION

1) Power on the **MFC** and your last paired device Bluetooth.

2) Ensure you are within range of the MFC, the unit will now automatically reconnect

3) If the device is out of range from the **MFC**, it will disconnect automatically: a. The *MFC* will reconnect automatically to your device when in range

4) If your device was previously paired with the **MFC**, but it wasn't the last paired device:

a. Ensure no other devices are currently paired

b. Enter the *Bluetooth Menu* on your device being paired


c. "BOSS REBEL UTV" will display under AVAILABLE DEVICES d. Choose the "BOSS REBEL UTV" to reconnect


5) To clear all previously paired devices from memory, press and hold the MFC Bluetooth button for 10 seconds

NOTE: Some devices may require a manual **Bluetooth** reconnection once the devices Bluetooth is powered OFF / ON and/or back in range, repress the BOSS REBEL UTV button in BLUETOOTH settings on your device

Using this product without running the engine can drain the battery. To avoid battery exhaustion, be sure to occasionally run the vehicles engine while using this product.

MOUNTING THE SOUNDBAR





1) Determine the size rollbar for your vehicle, install rubber bushings on rollbar 2) Insert and align notch of rubber bushings into the aluminum brackets 3) Apply supplied Loc-Tight to allen bolt tips, let dry for 20 minutes, then align the allen bolts and T-nuts into the T-channel, firmly tighten 4) Recheck all allen bolts are tight, ensure T-nut's are properly seated in the *T-channel* correctly

CAUTION!!

Mounting brackets should be periodically checked to be sure they are tight and secure before use of the vehicle

BEFORE YOU START

IMPORTANT SAFETY PRECAUTIONS

B

■ Do not operate mobile equipment while driving a motorized vehicle – safe driving and safety consideration of others should always be your highest priority ■ In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized BOSS AUDIO Service Center. Using this product in this condition may result in

permanent damage to the system ■ Set your volume control at a low setting, then slowly increase the sound until you can

hear it comfortably without distortion, or ear discomfort

- Use caution or temporarily discontinue use in potentially hazardous situations

■ BE SURE TO OBSERVE THE FOLLOWING GUIDELINES: - Do not turn up the volume so high that you can't hear what's around you

INSTALLATION PRECAUTIONS

WARNING - Always consult a professional installer

■ Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards

■ Refer any repairs to a qualified **BOSS AUDIO SYSTEMS** Service Center ■ The *BRRC34* should be hard wired directly to the main vehicle battery ■ When wiring directly to the vehicles battery, be sure to disconnect the batteries negative

terminal wire before starting any wiring procedures ■ The ground cable length should be short as possible (See wiring diagram)

■ The *BRRC34* has a weather resistant design, it should not be under any circumstances

■ Use only the supplied installation parts provided with the *BRRC34* Wash with a mild detergent and lukewarm water using a clean sponge or a soft cloth

Rinse well with clean water

"DO NOT'S" - Very Important DON'T clean in hot sun or on very hot days ■ DON'T use abrasive or highly alkaline cleaners on the main body

■ DON'T scrape the main body with razor blades, or other sharp instruments ■ DON'T ever use, gasoline, acetone or carbon tetrachloride ■ DON'T ever use a pressure washer aimed at the speakers

STREAMING MUSIC

0

CAUTION!! Using other mounting methods may void this warranty

MULTIFUNCTION CONTROLLER BLUETOOTH OPERATION

1) Press the **5 PLAY/PAUSE** once to start playing music or press the **PLAY** button from your devices touch screen

2) To skip songs or advance, press the 4 NEXT TRACK button

3) To select the previous song, press the 7 **PREVIOUS TRACK** button

VOLUME CONTROL

0

4) To raise the volume press the **9 VOLUME UP** button or use your devices controls 5) To lower the volume press the **8 VOLUME DOWN** button or use your devices controls

NOTE: If BLUETOOTH or AUX is disconnected for more than 10 minutes the MFC will automatically turn OFF, however, when not in use the ACC switch should be manually turned **OFF** to keep the vehicles main battery from draining

Make sure your device Bluetooth volume is set at 100% level before stowing your device

MULTI-FUNCTION CONTROLLER MOUNTING MFC can rotate 90° for the

ROLLBAR / CAGE MOUNT

FLUSH MOUNT



1) Always check mounting depth before cutting 2) Use the flush bezel as template 3) Cutout hole exactly 4) Insert flush mount bezel, push side tabs outwards 5) Use optional silicon glue to give extra hold

6) Insert MFC

1) Check mounting depth before drilling 2) Use the flush bezel as template 3) Drill or cut wire hole exactly 4) Insert rubber trim around flush bezel, screw in place 5) Insert MFC

OPTIONAL TOOLS NEEDED: TOOLS NEEDED: - Crimp Tool - Wrench or Pliers - 3mm Allen Wrench

- Hand saw or Jigsaw

NEXT TRACK - FF press and hold PLAY/PAUSE - AUX MUTE BLUETOOTH PAIRING INDICATOR LED - BLUE / AUX RED COLOR PREVIOUS TRACK - FR press and hold **VOLUME DOWN - Ramp DOWN press and hold** (9) VOLUME UP - Ramp UP press and hold **AUX-INPUT** (9) **DEVICE**

GETTING STARTED

GETTING TO KNOW YOUR

BRRC34 MULTIFUNCTION CONTROLLER (MFC)

DOME LIGHT ON/OFF - (Auto 10 minute timer when MFC ACC is turned OFF)

EQ - EQ1 | EQ2 | EQ3 | FLAT - EQ1 Default Press and hold for 3 seconds

MFC RESET

3.5mm AUX-INPUT

Close USB cover when not in use

CAUTION!! Never use USB or AUX while in mud and/or water

MFC can play audio from

headphone audio jack.

any device that has a 3.5mm

4

USB 1A

CHARGING

ALWAYS CLOSE COVER WHEN

IN MUD and/or WATER

NOT IN USE NEVER USE WHEN OPEN

(A) MFC - MULTIFUNCTION CONTROLLER

POWER ON - Press and hold for 3 seconds

MULTIFUNCTION CONTROLLER AUX-IN OPERATION

1) Power on the *MFC* by pressing and holding down the **3** *POWER* button for 3 seconds 2) Disconnect any paired *Bluetooth* device by turning off *Bluetooth* in your devices Settings Menu

3) Connect your 3.5mm **AUX-IN** cable located on front side of the **MFC** to your devices headphone jack

4) Route the wire back to **MFC**, secure your device in a safe location


VOLUME CONTROL

Version: 4.1

5) To raise the volume press the **YOLUME UP** button 6) To lower the volume press the **8 VOLUME DOWN** button

7) To **MUTE** the volume press the **5 PLAY/PAUSE** button

Make sure your device headphone volume is set at 100% level before stowing your device



• A2DP / AVRCP / GATT Range: 33ft (10m) Class 2

Weight: 19.84lbs / 9.00kg
Dimensions Inches WxHxD: 33.77 x 4.98 x 5.55

 Operational Power: 14.4VDC (10-16V allowable) MAX Current Draw: 12.7A
 USB Charging: 1A @ 5VDC +/- 5% Dimensions cm WxHxD: 85.8 x 12.6 x 14.1 Operation Temperature: 32°F to 140°F / 0°C to 60°C Cabinet Material: Aluminum Extrusio SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

SPECIFICATIONS

• RCA Line Output: 2V RMS Cone Type: PP CARBON Tweeter Size: 1" SOFT DOME

 Maximum Output Power: 700 Watts Input Impedance: 10kΩ
Frequency Response: 45Hz-25kHz